




# Zone 2 (master map for whole building)

- Fire fighting equipment
- Alarm point
- Route 1
- Route 2 alt./disabled
- Route 3 inc. disabled
- Route 4 inc alt.
- Route 5
- No pushbar. Exit may be locked or unsuitable for some.
- 1234 Information points numbered by zone



To Assembly Point  
(See map)